

YAESU


Radio for Professionals

C4FM/FM 144/430MHz
DUAL BAND DIGITAL TRANSCEIVER

FTM-310DR

FTM-310DE

Instruction Manual
(WIRES-X Edition)




Contents

What is WIRES-X?	3
Terminology	4
Connecting to a Distant Station Using WIRES-X	7
Finding a local node	7
Connecting in digital mode	8
Connecting to a WIRES-X digital node	8
Connecting to a node or room on the Internet	9
Communicating with others	11
Release the WIRES-X connection	11
Useful functions in digital mode	12
Using preset channels	12
Connecting to registered nodes or rooms	13
Connecting to analog nodes	15
Connecting to nodes or rooms on the Internet	15
Communicating with others	15
Disconnecting from the node or room	15
Using WIRES-X Digital Node News Function	16
Viewing messages	16
Viewing text data in local nodes	16
Viewing text data on the WIRES-X server (INT NEWS)	17
Viewing text data in nodes or rooms on the Internet	17
Viewing imported data later	18
Deleting imported data	18
Deleting a file	18
Listening to audio messages	19
Listening to emergency information in the local node	19
Listening to routine messages in local nodes	20
Listening to routine messages on the WIRES-X server (INT NEWS)	20
Listening to emergency information in nodes or rooms on the Internet	20
Listening to routine messages in nodes or rooms on the Internet	21
Transmitting messages and images	21
Creating and transmitting messages to local nodes	21
Transmitting saved messages or images to local nodes	22
Creating and transmitting messages to nodes or rooms on the Internet	22
Transmitting saved messages or images to nodes or rooms on the Internet	22
Transmitting audio messages	23
Transmitting emergency information to local nodes	23
Transmitting routine voice messages to local nodes	23
Transmitting emergency information to nodes or rooms on the Internet	23
Transmitting routine messages to nodes or rooms on the Internet	24
WIRES-X Setup Menus	25
WIRES-X setting mode list	25
Using the WIRES-X setup menu	25
65 RPT/WIRES FREQ	25
66 SEARCH SETUP	25
67 EDIT CATEGORYTAG	25
68 DELETE ROOM/NODE	26
69 WIRES DG-ID	26
Using the FTM-310DR/DE transceiver as a node station	27
Set the FTM-310DR/DE to node station mode	27

What is WIRES-X?

WIRES (Wide-coverage Internet Repeater Enhancement System) is an Internet communication system which expands the range of amateur radio communication. By relaying radio signals via the Internet, stations can be connected where radio waves cannot reach each other.

WIRES uses local nodes (stations connected to the Internet via PCs) as access points which repeat communications of conventional amateur radio stations. When the local nodes are connected to each other via the Internet, amateur stations all over the world can communicate with each other just by connecting conventional stations to the local nodes.



In addition to the WIRES features, WIRES-X also supports digital communications. Using WIRES-X, you can transmit and receive digitalized data such as text, image data and audio.

Using WIRES-X in conjunction with the transceiver allows analog/digital communications with stations beyond the direct radio contact range. In digital communication mode, you can search for stations by call signs or keywords, and exchange data such as messages and location information.

Terminology

■ Node

Radio repeater connected to the Internet via a PC, creating an internet WIRES access point which repeats signals of conventional amateur radio stations.

● Local node


Node within the radio contact range of a conventional amateur radio station.

● Analog node

An analog node is a transceiver or repeater using the conventional FM format, that can only repeat DTMF (Dual Tone Multi Frequency) codes, and analog audio transmissions.

● Digital node

A Digital node is a transceiver or repeater compatible with digital communications in C4FM (Continuous 4 level FM) format. This type of node can transmit/receive digital audio, as well as text and image data. You can also repeat DTMF codes and analog audio transmissions.



■ WIRES-X user ID

YAESU provides identification names with the WIRES-X nodes. For each node, a DTMF ID (5-digit number) and an alphanumeric user ID (up to 10 digits) are assigned. If the ID of the node to be connected is known, you can transmit the DTMF code from the transceiver, or directly specify the node to connect by searching the digital characters (only for digital nodes).

● ID list

Nodes and rooms which are currently operating WIRES are listed and published on the Yaesu website. Information such as the IDs, the call signs and the operating frequencies is provided (some nodes may not be published due to the wishes of the owners).

■ Room (Round QSO Room)

WIRES system creates community space QSO Rooms to which multiple nodes can connect simultaneously. Besides voice communications, you can also chat with text messages on the local node control PC.

● Open room

Room which allows all nodes to connect

● Closed room


Room only registered nodes can connect

● Digital room

Room only digital nodes can connect

● Activity

Nodes currently connected to a specific room




Tip: In the illustration, **D** refers to digital nodes and **A** refers to analog nodes.

■ News function

This feature allows digital data such as text, image, and audio, to be saved on the local node control PC. The data can be accessed from the connected digital stations.

From a digital transceiver connected to a local node or room, you can access the local node (LOCAL NEWS) and the data storage area (news station), and import (upload) and export (download) data.

Owners of a node or room can import/export data from/to their own station via a PC. The owner can also delete data and change information such as its name and attribution. The WIRES-X server also has its own news station (INT NEWS) where you can read information and data supplied by YAESU.



■ Preset search function

If the preferred channel for connecting to a local node is programmed (preset) in the transceiver, the channel can be scanned automatically when WIRES-X is started.

Utilize this function as follows:

- Quickly connect to the usually accessed local node by presetting its frequency in advance.
- By presetting a channel frequency shared with your friends nodes, you can quickly connect the transceiver to a local node even while traveling in other areas.

Two transceivers can be used on the node, one for the preset search channel (receive only channel) and the other for the voice channel (operation channel).

Connecting to a Distant Station Using WIRES-X

Finding a local node

To communicate with WIRES-X, a WIRES-X node station (local node) must be established within radio contact range of the user transceiver.

WIRES-X nodes are stations users voluntarily registered with Yaesu. Their information such as locations and operation styles are listed on the Yaesu website:

<https://www.yaesu.com/jp/en/wires-x/index.php>

First use this list to search for a nearby local WIRES-X node, and then find nodes on the Internet used by people you want to communicate with; write down the node names and frequencies. Since the connection procedure differs between digital stations and analog stations, confirm whether the node is an analog station or a digital station.

- When the local node is a digital station:
Connect from your transceiver in digital mode.
(Nodes on the Internet can connect to both digital and analog stations.)
- When the local node is an analog station:
Connect from your transceiver in analog mode.
(Nodes on the Internet can connect to both analog and digital stations.)

Connecting in digital mode

- Ascertain the DG-ID setting of the WIRES-X node station. Connecting to the WIRES-X node requires the transceiver DG-ID be set according to the DG-ID code set on the WIRES-X node station.
- Confirm that the operating mode of WIRES-X node has been set to the C4FM digital mode.
- Before using WIRES-X, set the communication modulation mode to C4FM.

Connecting to a WIRES-X digital node

1. Set the transmit/receive DG-ID to the same ID number as the node station.
For details, refer to the FTM-310DR/DE Operating Manual.



The DG-ID number set by this connection method is the normal DG-ID number. Please note that this is not the WIRES-X DG-ID number set in **[69 WIRES DG-ID]** in the setup menu.

2. Transmit with the corresponding node transmit/receive frequency.
 - If the signal is received from the node, continue to operate as is.
 - If not receiving the signal from the node, it is possible that the node station is not connected to the Internet, if so, proceed to the next step "Connecting to the other node ID or the other room ID".

■ Connecting to the other node ID or the other room ID

1. Press and hold the **[F/BACK]** key → **[69 WIRES DG-ID]** →
Press the Right **DIAL** knob.

The WIRES-X DG-ID setting screen will be displayed.



2. Rotate the Right **DIAL** knob to set the WIRES-X DG-ID to the same ID number as the node station.

AUTO: Only open nodes, set to the DG-ID number "00" may be connected.

01 to 99: Only nodes matching the set DG-ID number may be connected.

The default setting is "AUTO"

3. Press any key or **DIAL** knob, other than the **[F/BACK]** or **[ON/OFF]** key, to save the settings and return to normal operation.

4. Set the frequency of the desired local node.

5. Press the **[F/BACK]** key.

6. Rotate the Right **DIAL** knob to select the **[WIRES-X]**, then press the Right **DIAL** knob.

"**[X]**" flashes on the left side of the display.



When a local node cannot be found, "**[X]**" will disappear in 20 seconds.

7. When a local node is found, "**[X]**" is lit solid, and the node name and city name appear on the bottom part of the screen.

Connecting to a node or room on the Internet

Connect to the chosen node or room in one of the following ways:

- Select an accessible node or room from the list
- Specify the node name or room name
- Select the most recently connected node or room
- Specify the DTMF ID of the node or room to connect

● Searching from the node & room lists

1. While displaying the local node, rotate the Right **DIAL** knob to select [**SEARCH & DIRECT**], then press the Right **DIAL** knob.

The category list is displayed.



2. Rotate the Right **DIAL** knob to select [**ALL**], then press the Right **DIAL** knob.

- Displays the list of accessible nodes and rooms.
- Connection destinations are displayed from the room list and then node list.
- On the connection destination room columns, the number of activities (the number of nodes connected to each room) appears on the right side.



3. Rotate the Right **DIAL** knob to select the node or room to connect, then press the Right **DIAL** knob.

Rotate the Right **DIAL** to select the node or room to connect, then press **PTT** to establish a connection.

- Once connection is successful, the menu list of the connected node (room) will appear.
- If connection is unsuccessful, an error message appears, and the screen returns to the list of nodes and rooms.

● Searching by node or room name

1. While displaying the local node, rotate the Right **DIAL** knob to select [**SEARCH & DIRECT**], then press the Right **DIAL** knob.

The category list is displayed.



2. Rotate the Right **DIAL** knob to select [**SEARCH & DIRECT**], then press the Right **DIAL** knob.

The character input screen is displayed.

3. Enter all or part of the room or node name, then press and hold the Right **DIAL** knob.



If connection destinations with the first part of the name matching the partial entry are found, they will be listed.

- If there are no connection destinations matching the partial entry, “No Data” appears and the screen returns to the character input screen.
 - If the entered name is found, the transceiver establishes connection immediately.
 - The screen displays the room list search results followed by the node list search results.
 - On the room search results, the number of nodes connected to each room appears on the right side.
4. Rotate the Right **DIAL** knob to select the node or room to connect, then press the Right **DIAL** knob.
 - Rotate the Right **DIAL** to select the node or room to connect, then press **PTT** to initiate a connection.
 - Once connection is successfully established, the menu list of the connected node (room) will appear.
 - If connection is unsuccessful, an error message appears and the screen returns to the list of nodes and rooms.

● Connecting to the most recently connected node or room

The previously Internet connected node or room, appears and flashes at the bottom of the screen.

Rotate the Right **DIAL** knob to select the flashing node or room, then press the Right **DIAL** knob or the **PTT** switch to start the connection, when established, the menu list of the connected node (room) will appear.

- If “►” is displayed at the left side of the node name on the bottom part of the screen, rotate the Right **DIAL** knob to display the node most recently connected.
- If connection is not successful, an error message appears, and the screen returns to the list of nodes and rooms.

● Specify the DTMF ID of the node or room to connect

1. While the WIRES-X connection screen is displayed, press and hold the “#” key on the microphone.
“#” Is displayed in the frequency display area.
2. Enter the DTMF ID on the microphone, then press the “#” key.
 - The connection begins and DTMF ID flashes.
 - Once connection is established, the menu list of the connected node (room) will appear.
 - To discontinue the input, press the “*” key on the microphone.
 - If connection is unsuccessful, an error message appears.



Communicating with others

1. While displaying the station you are currently connected to, press **PTT** switch.
The transceiver switches to transmit.
2. Release the **PTT** switch.
The transceiver returns to receive.

● Disconnecting from the node or room

1. Press and hold the “*” key on the microphone.

Release the WIRES-X connection

Press the  key to disconnect and switch to the frequency display screen, the “ ” on the left side of the frequency display disappears.

If the disconnect operation is not performed, the local node and the node or room remain connected.

Useful functions in digital mode

Using preset channels

Programming (presetting) a channel frequency allows you to easily connect to a local node.

By sharing a channel frequency with other nodes, you can connect the transceiver to a local node even while you are out. This is useful for a group to operate a station.

● Presetting a channel

1. Press and hold the  key → **[65 RPT/WIRES FREQ]** → Press the Right **DIAL** knob.
2. Press the Right **DIAL** knob, then rotate the Right **DIAL** knob to select **[PRESET]**.
 - “PRESET” will become available.
 - The default setting is “MANUAL”.
3. Press the  key.
4. Rotate the Right **DIAL** knob to select frequency, then press the Right **DIAL** knob.
 - Press the  key to switch the preset frequency band.
 - The default setting is 146.550 MHz, 446.500 MHz.
5. Press any key or **DIAL** knob, other than the  or  key, to save the settings and return to normal operation.

65 RPT/WIRES FREQ	
FREQUENCY	PRESET
	146.550 MHz

● Stop using preset channels

Set step 2 of the previous section to “MANUAL”.

● Connecting to a preset channel

1. Follow the above procedure “Presetting a channel” to make the preset channel available in advance.
2. Press the  key.
3. Rotate the Right **DIAL** knob to select the **[WIRES-X]**, then press the Right **DIAL** knob.

The preset frequency is recalled, and the “P” and “ ” icons flash alternately in the upper left of the frequency display.
4. When a local node is found, “ ” lights up, and the node name and city name appear on the bottom part of the screen.

When a local node cannot be found, the flashing “P” and “ ” disappear in 20 seconds.



If the frequency of the detected local node is different from that of the preset channel, the frequency automatically switches to the node frequency.

Connecting to registered nodes or rooms

Register names of Internet nodes and rooms on the Internet and sort them into 5 categories. Up to a total of 20 nodes and rooms can be registered in each category.

● Registering category names

1. Press and hold the  key → [67 EDIT CATEGORY TAG] → Press the Right **DIAL** knob.
2. Rotate the Right **DIAL** knob to select one of [C1] to [C5], then press the Right **DIAL** knob.
The character input screen is displayed.
3. Enter the category name.



4. Press and hold the Right **DIAL** knob knob to set the category name and return to the previous screen.
Repeat steps 2 to 3 to set more category names.
5. Press any key or **DIAL** knob, other than the  or  key, to save the settings and return to normal operation.

● Registering a node or room

1. Rotate the Right **DIAL** knob to select the node or room to connect, then press the Right **DIAL** knob.
The menu list of the connected node (room) is displayed.
2. Press the Left **DIAL** knob.
3. Rotate the Left **DIAL** knob to select [ADD], then press the Left **DIAL** knob.
The category list displayed.
4. Rotate the Right **DIAL** knob to select one of [C1] to [C5], then press the Right **DIAL** knob.
The name of the currently connected node or room is added to the registered node and room lists.
5. Press the  key.
The screen returns to the list.

● Connecting to registered nodes or rooms

1. Rotate the Right **DIAL** knob to select [SEARCH & DIRECT], then press the Right **DIAL** knob.
The category list is displayed.
2. Rotate the Right **DIAL** knob to select one of [C1] to [C5], then press the Right **DIAL** knob.
 - Displays the node and room lists.
3. Rotate the Right **DIAL** knob to a node or room, then press the Right **DIAL** knob.
Rotate the Right **DIAL** knob to select the node or room to connect, then press **PTT** to switch to establish a connection.



The items are listed in the order of the activity number, or the access history (as selected from **[66 SEARCH SETUP]** in setting mode).

- If connection is successful, the menu list of the connected node or room appears.
- If connection is not successful, an error message appears, and the screen returns to the list of nodes and rooms.

Connecting to analog nodes

When the node to connect is an analog station, use the DTMF function on the transceiver. For details on using the DTMF function, refer to “DTMF Operation” in the Advance Manual.

Connecting to nodes or rooms on the Internet

1. Set the main band frequency to the local node frequency.
2. Press the **[SQL/VOL]** knob to switch to analog FM mode.
For details, refer to “Selecting the Communication Mode” in the basic operating manual.
3. While pressing the microphone **PTT** switch, also press the DTMF ID key “#” followed by the 5 digits of the room or node to connect.
4. Release the **PTT** switch on the microphone, and keep the transceiver in receiving mode for about 10 seconds.
 - Once connection is established, you will be able to hear audio.
 - The connection destination screen does not appear.



DTMF codes consisting of up to 16 digits can be stored into 9 channels on the transceiver. If you register the codes of frequently-used connection destinations in advance, you can easily transmit the code by selecting it on the function menu screen and pressing PTT. For details, refer to “DTMF Operation” in the Advance Manual.

Communicating with others

1. Press the **PTT** switch, and speak into MIC.
2. Release the **PTT** switch.
The transceiver switches to receive mode.

Disconnecting from the node or room

1. While pressing the **PTT** switch on the microphone, also press “#” followed by “99999” (DTMF disconnect command).
2. Disconnects the node or room.

Using WIRES-X Digital Node News Function

In WIRES-X digital mode, you can transmit/receive messages (text data) and images; you can also record/play audio messages.



Before using the News function, insert a microSD memory card into the transceiver. For details, refer to "Using a micro SD Memory Card" in the basic operating manual.

Viewing messages

Text messages and data that are transmitted/received by either a local node, or a node or room on the Internet, can be read on the transceiver.

Viewing text data in local nodes

1. On the connected destination screen, rotate the Right **DIAL** knob to select local node, then press the Right **DIAL** knob.
2. Rotate the Right **DIAL** knob to select the local node name displayed in [**LOCAL NEWS**], then press the Right **DIAL** knob.
If data reception is successful, the menu list of the local node appears.
3. Rotate the Right **DIAL** knob to select [**NEWS STATION**], then press the Right **DIAL** knob.
The upload/download select screen will appear.
4. Rotate the Right **DIAL** knob to select [**DOWNLOAD**], then press the Right **DIAL** knob.
The data type select screen will appear.
5. Rotate the Right **DIAL** knob to select [**MESSAGE**], then press the Right **DIAL** knob.
 - If data reception is successful, the list of data appears.
 - The list shows the registered data in reverse chronological order.
6. Rotate the Right **DIAL** knob to select the message to view, then press the Right **DIAL** knob.
Downloads the data and displays the content of the message.
7. Press the  key.
Returns the screen to the data list.



On each screen, press the  key to return to the previous screen.

Viewing text data on the WIRES-X server (INT NEWS)

Text information provided by Yaesu on the WIRES-X server can be read from the transceiver.

1. Rotate the Right **DIAL** knob to select local node, then press the Right **DIAL** knob.
2. Rotate the Right **DIAL** knob to select the local node name displayed in [**LOCAL NEWS**], then press the Right **DIAL** knob.
If data reception is successful, the menu list of the local node appears.
3. Rotate the Right **DIAL** knob to select [**INT NEWS**], then press the Right **DIAL** knob.
Displays the menu of the WIRES-X server.
4. Rotate the Right **DIAL** knob to select [**NEWS STATION**], then press the Right **DIAL** knob.
Displays the data type select screen.
5. Rotate the Right **DIAL** knob to select [**MESSAGE**], then press the Right **DIAL** knob.
 - If data reception is successful, the list of data appears.
 - The list shows the registered data in reverse chronological order.
6. Rotate the Right **DIAL** knob to select the message to view, then press the Right **DIAL** knob.
 - Downloads the data and displays the content of the message.
7. Press the  key.
Returns the screen to the data list.

Viewing text data in nodes or rooms on the Internet

1. Rotate the Right **DIAL** knob to select the Internet node or room to connect, then press the Right **DIAL** knob.
Displays the menu list of the Internet node or room.
2. Follow steps 3 to 7 of “Viewing text data in local nodes” (page 16) to import the data.

Viewing imported data later

You can also view the imported data later.

1. Follow steps 1 to 2 in “Viewing text data in local nodes” (page 16) to display the data type select screen.
2. Press the Right **DIAL** knob twice.
Displays the data type select screen.
3. Rotate the Right **DIAL** knob to select [**MESSAGE**], then press the Right **DIAL** knob.
 - Displays the data list.
 - The list shows the registered data in reverse chronological order.
4. Rotate the Right **DIAL** knob to select the data to view, then press the Right **DIAL** knob.
Displays the content of the message or the image.
5. Press the  key.
Returns the screen to the data list.

Deleting imported data

Deleting a file

1. Follow steps 1 to 4 “Viewing imported data later” to display the content of the message or image data.
2. Press the Left **DIAL** knob, then rotate the Left **DIAL** knob to select [**DEL**], then press the Left **DIAL** knob.
The confirmation message appears.
3. Rotate the Left **DIAL** knob to select [**OK**], then press the Left **DIAL** knob.
Deletes the data and returns the screen to the data list.

Listening to audio messages

You can play and listen to audio files transmitted/received by a local node, or node or room on the Internet.

Audio files are categorized into the following two types:

EMERGENCY: Emergency information. Depending on the node or room settings, mandatory updates are supplied to connected nodes and rooms in five-minute intervals for two hours starting from the initial dissemination of the news.

NEWS STATION: Normal message. Listen to the message anytime, as long as the message is not deleted from the node or room.



VOICE data of the news function cannot be imported to the transceiver.

Listening to emergency information in the local node

1. Follow steps 1 to 2 in “Viewing text data in local nodes” on page 16 to display the menu list of the local node.
2. Rotate the Right **DIAL** knob to select [**EMERGENCY**], then press the Right **DIAL** knob.
 - Displays the data list.
 - The list shows the registered data in reverse chronological order.
 - Data registered within the past 2 hours flashes.
3. Rotate the Right **DIAL** knob to select the audio file to play, then press the Right **DIAL** knob.
 - Audio playback begins and the speaker icon flashes.
 - After playback ends, the screen returns to the data list.

Listening to routine messages in local nodes

1. Follow steps 1 to 4 in “Viewing text data in local nodes” on page 16 to display the data type select screen.
2. Rotate the Right **DIAL** knob to select [**VOICE**], then press the Right **DIAL** knob.
 - Displays the data list.
 - The list shows the registered data in reverse chronological order.
3. Rotate the Right **DIAL** knob to select the audio file to play, then press the Right **DIAL** knob.
 - Audio playback begins and the speaker icon flashes.
 - After playback ends, the screen returns to the data list.

Listening to routine messages on the WIRES-X server (INT NEWS)

1. Follow steps 1 to 4 in “Viewing text data on the WIRES-X server (INT NEWS)” on page 17 to display the data type select screen.
2. Rotate the Right **DIAL** knob to select [**VOICE**], then press the Right **DIAL** knob.
 - Displays the data list.
 - The list shows the registered data in reverse chronological order.
3. Rotate the Right **DIAL** knob to select the audio file to play, then press the Right **DIAL** knob.
 - Audio playback begins and the speaker icon flashes.
 - After playback ends, the screen returns to the data list.

Listening to emergency information in nodes or rooms on the Internet

1. Rotate the Right **DIAL** knob to select the node or room on the Internet to connect, then press the Right **DIAL** knob.

Displays the menu list of the node or room on the Internet.
2. Follow steps 3 to 4 in “Viewing text data in local nodes” on page 16.
3. Rotate the Right **DIAL** knob to select [**EMERGENCY**], then press the Right **DIAL** knob.

Displays the data list.

 - The list shows the registered data in reverse chronological order.
 - Data registered within the past 2 hours flashes.
4. Rotate the Right **DIAL** knob to select the audio file to play, then press the Right **DIAL** knob.
 - Audio playback begins and the speaker icon flashes.
 - After playback ends, the screen returns to the menu list of the connected node or room.

Listening to routine messages in nodes or rooms on the Internet

1. Rotate the Right **DIAL** knob to select the Internet node or room to connect, then press the Right **DIAL** knob.
Displays the menu list of the node or room on the Internet.
2. To play the audio, follow steps 2 to 3 in “Listening to routine messages in local nodes” on page 20.

Transmitting messages and images

You can transmit messages (text data) and images saved on the microSD memory card inserted into the transceiver, to a local node, or a node or room on the Internet. You can also create a new message and transmit it.

Creating and transmitting messages to local nodes

1. Follow steps 1 to 3 in “Viewing text data in local nodes” on page 16 to display the upload (transmission)/download (reception) select screen.
 2. Rotate the Right **DIAL** knob to select [**UPLOAD**], then press the Right **DIAL** knob.
Displays the data type select screen.
 3. Rotate the Right **DIAL** knob to select [**MESSAGE**], then press the Right **DIAL** knob.
Displays the data list.
 4. Rotate the Right **DIAL** knob to select [**NEW**], then press the Right **DIAL** knob.
 5. Press the Left **DIAL** knob, then rotate the Left **DIAL** knob to select [**EDIT**], then press the Left **DIAL** knob.
 6. Use the Right **DIAL** knob to enter a message of up to 80 characters.
 7. Press and hold the Right **DIAL** knob.
Displays the entered message confirmation screen.
 8. Press the Left **DIAL** knob, then rotate the Left **DIAL** knob knob to select [**UPLOAD**], then press the Left **DIAL** knob.
 - Starts message transmission.
 - To save the entered message as a standard message, rotate the Left **DIAL** knob to select [**SAVE**], then press the Left **DIAL** knob (page 22).
 - After message transmission completes, the screen returns to the data list.
-

1. On the character input screen, rotate the Right **DIAL** knob to select [**#%^**], then press the Right **DIAL** knob.
2. Rotate the Right **DIAL** knob to select [**MTXT**], then press the Right **DIAL** knob.
3. Rotate the Right **DIAL** knob to select one of the 19 routine messages, then press the Right **DIAL** knob.



QRM	QSY	Good night	Pick me up
QRP	Good morning	Send messages	Thank you
QRT	Good job	Send pictures	OK
QRX	Good day	on my way	urgent
QRZ	Good evening	wait for you	

● **Registering a standard message**

Up to 10 texts containing a maximum of 80 characters each can be registered as standard messages. Registered texts can be selected and used like the 19 standard messages that have been saved as default.

1. Follow steps 1 to 7 in “Creating and transmitting messages to local nodes” on page 21 to display the message entry screen.
2. Press the Left **DIAL** knob, then rotate the Left **DIAL** knob to select [**SAVE**], then press the Left **DIAL** knob.
The standard message list is displayed.
3. Rotate the Right **DIAL** knob to select the number (1 to 10) where you want to register the standard message.
4. Press the Right **DIAL** knob.
 - Registers the text as a standard message and displays the message entry screen.
 - If you register a new message to a number where a message is already registered, the old message is overwritten.

Transmitting saved messages or images to local nodes

1. Follow steps 1 to 2 in “Creating and transmitting messages to local nodes” on page 21 to display the data type select screen.
2. Rotate the Right **DIAL** knob to select [**MESSAGE**] or [**PICT**], then press the Right **DIAL** knob.
Displays the data list.
3. Rotate the Right **DIAL** knob to select the message or image to transmit, then press the Right **DIAL** knob.
4. Press the Left **DIAL** knob, then rotate the Left **DIAL** knob to select [**UPLOAD**], then press the Left **DIAL** knob.
After data transmission completes, “Completed” appears and then the screen returns to the data type select screen.

Creating and transmitting messages to nodes or rooms on the Internet

1. Rotate the Right **DIAL** knob to select the node or room on the Internet to connect to, then press the Right **DIAL** knob.
Displays the menu list of the node or room on the Internet.
2. Rotate the Right **DIAL** knob to select [**NEWS STATION**], then press the Right **DIAL** knob.
Displays the upload (transmission)/download (reception) select screen.
3. Rotate the Right **DIAL** knob to select [**UPLOAD**], then press the Right **DIAL** knob.
Displays the data type select screen.
4. Follow steps 3 to 8 in “Creating and transmitting messages to local nodes” on page 21 to create and transmit a message.

Transmitting saved messages or images to nodes or rooms on the Internet

1. Follow the above steps 1 to 3 in “Creating and transmitting messages to nodes or rooms on the Internet”, to display the data type select screen.
2. Follow the above steps 2 to 4 in “Transmitting saved messages or images to local nodes”, to select and transmit data.

Transmitting audio messages

You can transmit audio messages spoken into the microphone as data to a local node, or node or room on the Internet.

Audio files are categorized into the following 2 types:

EMERGENCY: Emergency information. Depending on the node or room settings, mandatory updates are supplied to connected nodes and rooms in five-minute intervals for two hours starting from the initial dissemination of the news.

NEWS STATION: Normal message. Listen to the message anytime as long as the message is not deleted from the node or room.

Transmitting emergency information to local nodes

1. Follow steps 1 to 2 in "Viewing text data in local nodes" on page 16 to display the menu list of the local node.
2. Rotate the Right **DIAL** knob to select [**EMERGENCY**].
3. Press the **PTT** switch, a beep sounds and a confirmation screen "EMERGENCY Upload?" Appears. When sending emergency information, press and hold the **PTT** switch, after three beeps, the screen display will change to "EMERGENCY UPLOADING" for about 5 seconds, and then the countdown will be started. While pressing the **PTT** switch, speak into MIC.
The maximum recording time is one minute.
4. Release the **PTT** switch after completing audio transmission.
After message transmission completes, "**Completed**" appears and then the screen returns to the menu list of the local node.

Transmitting routine voice messages to local nodes

1. Follow steps 1 to 3 in "Viewing text data in local nodes" on page 16 to display the upload (transmission)/download (reception) select screen.
2. Rotate the Right **DIAL** knob to select [**UPLOAD**], then press the Right **DIAL** knob. Displays the data type select screen.
3. Rotate the Right **DIAL** knob to select [**VOICE**], then press the Right **DIAL**.
4. While pressing the **PTT**, speak into MIC.
The maximum recording time is one minute.
5. Release the **PTT** after completing audio transmission.
After message transmission completes, "**Completed**" appears and then the screen returns to the data type select screen.

Transmitting emergency information to nodes or rooms on the Internet

1. Rotate the Right **DIAL** knob to select the node or room on the Internet to connect, then press the Right **DIAL** knob.
Displays the menu list of the node or room on the Internet.
2. Follow the above steps 2 to 4 in "Transmitting emergency information to local nodes" to transmit a message.

Transmitting routine messages to nodes or rooms on the Internet

1. Follow steps 1 to 2 in “Creating and transmitting messages to nodes or rooms on the Internet” on page 22 to display the upload (transmission)/download (reception) select screen.
2. Follow steps 2 to 5 in “Transmitting routine voice messages to local nodes” on page 23 to transmit a message.

WIRES-X Setup Menus

WIRES-X setting mode list

Setup Menu no. / item	Description	Selectable options (Options in bold are the default settings)
65 RPT/WIRES FREQ	Setting the operating frequencies for repeaters/WIRES-X	MANUAL / PRESET
	Setting preset frequencies	Depends on the transceiver version.
66 SEARCH SETUP	Setting the item order on the node & room lists	HISTORY / ACTIVITY
67 EDIT CATEGORYTAG	Editing category names	C1 to C5
68 DELETE ROOM/NODE	Deleting registered nodes/rooms	C1 to C5 1 to 20 in total in each category
69 WIRES DG-ID	Setting the DG-ID	01 to 99 / AUTO

Using the WIRES-X setup menu

65 RPT/WIRES FREQ

● Setting the operating frequencies for repeaters/WIRES-X

Can be set to always use the preset frequency when searching for the local node.

For details, refer to “Using preset channels” on page 12.

66 SEARCH SETUP

● Setting the item order on the node & room lists

To change the sort criteria of the list of connection destinations on the Internet:

1. Press and hold the  key → [66 SEARCH SETUP] → Press the Right **DIAL** knob.
2. Rotate the Right **DIAL** knob to select “**HISTORY**” or “**ACTIVITY**”.

HISTORY: Displays the list sorted in order of the connection destination that your station most recently connected to.

ACTIVITY: Displays the list sorted in descending order from the room with the most nodes connected. Nodes come after rooms.

3. Press any key or **DIAL** knob, other than the  or  key, to save the settings and return to normal operation.

67 EDIT CATEGORYTAG

● Editing category names

Five categories can be named where nodes and rooms are registered. Up to 16 alphanumeric characters can be used for each category name.

For details, refer to “Registering a node or room” on page 13.

68 DELETE ROOM/NODE

● Deleting the registered nodes and rooms

Nodes and rooms registered in the 5 categories can be deleted.

1. Press and hold the  key → **[68 DELETE ROOM/NODE]** → Press the Right **DIAL** knob.
2. Rotate the Right **DIAL** to select the desired category, then press the Right **DIAL** knob.
3. Rotate the Right **DIAL** to select the node or room to delete, then press the Right **DIAL** knob.
The confirmation message appears.
4. Rotate the Right **DIAL** knob to select **[OK]**, then press the Right **DIAL** knob.
Deletes the selected node or room.
5. Press any key or **DIAL** knob, other than the  or  key, to save the settings and return to normal operation.

69 WIRES DG-ID

● The DG-ID feature to access the WIRES-X node station

Set the WIRES-X, DG-ID number used when connecting to the local node station.

1. Press and hold the  key → **[69 WIRES DG-ID]** → Press the Right **DIAL** knob.
2. Rotate the Right **DIAL** knob to select the DG-ID setting for WIRES-X.

AUTO: Only open nodes, set to the DG-ID number “00” may be connected.

01 to 99: Only nodes matching the set DG-ID number may be connected.

The default setting is “AUTO”.

3. Press any key or **DIAL** knob, other than the  or  key, to save the settings and return to normal operation.

Using the FTM-310DR/DE transceiver as a node station

Set the FTM-310DR/DE to node station mode

Follow the procedure below to use the FTM-310DR/DE transceiver as a node station.

1. Connect the FTM-310DR/DE to the HRI-200, then start the WIRES-X software on the PC.

Refer to the HRI-200 Instruction Manual.

2. While pressing  and  simultaneously, press and hold the  switch to turn the power ON.

The FTM-310DR/DE will be set to node station mode; “**WIRES-X**” will appear on the display.

Follow step 2 again to cancel node station mode.

YAESU

Radio for Professionals

Copyright 2025
YAESU MUSEN CO., LTD.
All rights reserved.

No portion of this manual may be
reproduced without the permission of
YAESU MUSEN CO., LTD.

YAESU MUSEN CO., LTD.

Omori Bellport Building D-3F
6-26-3 Minami-Oi, Shinagawa-ku, Tokyo, 140-0013, Japan

YAESU USA

6125 Phyllis Drive, Cypress, CA 90630, U.S.A.

YAESU UK

Unit 4, Concorde Park, Concorde Way, Segensworth North,
Fareham, Hampshire PO15 5FG, United Kingdom